

# SWIIDINTER™ CORD SWITCH

## Advanced Settings

### Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration parameters can be modified to better adapt functionalities to specific user needs or to activate advanced features.

#### Switch All (Parameter Size 1)

Value	Description
0	Disabled
1	Switch on only
2	Switch off only
255	Fully enabled (Default)

### Command Classes

Supported Command Classes	Controlled Command Classes
<ul style="list-style-type: none"><li>• Basic (version 1)</li><li>• Association (version 2)</li><li>• Version (version 1)</li><li>• Manufacturer Specific (version 1)</li><li>• Switch All (version 1)</li><li>• Switch Binary (version 1)</li></ul>	