

SWIIDPLUG™ ADAPTER PLUG

Advanced Settings

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration parameters can be modified to better adapt functionalities to specific user needs or to activate advanced features.

Switch All (Parameter Number ●, Parameter Size 1)

Value	Description
0	Disabled (Default)
255	Enabled

Command Classes

Supported Command Classes	Controlled Command Classes
<ul style="list-style-type: none">• Basic (version 1)• Association (version 2)• Version (version 1)• Manufacturer Specific (version 1)• Switch All (version 1)• Switch Binary	